


If Hole is 3/16", then use Socket Head Cap Bolt in both holes
 Holes should be completely filled with cap of bolt



If Hole is 1/4", then use Button Head Cap Bolt in both holes
 Holes should be completely filled with cap of bolt

USE BLUE THREAD LOCKER
 ON ALL SCREWS



NEXT ASSY.:
 SUPERSEDES:
 DO NOT SCALE DRAWING

TITLE
 K9034 Screw Instructions

REV.	BY	DATE	DESCRIPTION

MAT'L SPEC.

*THIS DRAWING IS THE PROPERTY OF A&M SYSTEMS, INC.
 AND IS NOT TO BE DUPLICATED OR USED IN ANY WAY
 DETRIMENTAL TO THEIR BEST INTEREST.*

TOLERANCE UNLESS SPECIFIED		DRAWING INFORMATION	
Fractions: +/- 1/32		DRAWN: bmilller	CKD:
Decimals: .000 +/- .005		DATE: 2/29/2016	SIZE: A
Angles: +/- 1 Deg.		SCALE: 1:2	WT.:

PART NUMBER PAGE
1 OF 1